

# SPB Mobile Shell 3.5

**User Manual** 



#### Copyright Notice

© 2009 SPB Software. All rights reserved. Information in this manual is subject to change without notice and does not represent a commitment on the part of SPB Software. All company and product names mentioned in the manual may be trademarks or registered trademarks of their respective owners.



# **Table of Contents**

Table of Contents	2
Overview	3
Software Features	3
Installation	
System Requirements	5
Installing	5
Registration	5
Uninstalling	
Getting Started	
SPB Home	
Launcher Tab	11
Contacts Tab	12
SPB Mobile Shell Tools	13
SPB Mobile Shell Settings	14
System	14
Home Screen	14
Animation	14
Agenda View	15
Weather	15
Backup your Settings	15
Exiting from SPB Mobile Shell	15
Technical Support	16
About The Trial Version	16
Before Contacting Technical Support	16
Contacting Technical Support	



36 월∥ ◀₭ 🚾

Thursday, September 24

Fri 6:00 AM (in 7 hrs 24 mins)

### Overview

SPB Mobile Shell introduces the next generation of a user interface while keeping all the advantages of a Windows Mobile device. SPB Mobile Shell 3.0 brings the perfect usability balance to Windows Mobile touch screen devices. You will be able, while only using one hand, to get information, launch programs, make calls and navigate your device in a simple and flexible manner. Enjoy your Windows Mobile phone!

#### **Software Features**

#### **New Tabbed Pages**

The main tabs has a new and fresh design for the Windows Mobile interface, thumb optimization icons at the bottom for quick access, changing page with gesture, and animated transitions.

- Home: The Home Lifestyle layout helps you save time by bringing your favorite contacts, items, and services right to you. You can fully customize the layout in a user friendly manner using drag-and-drop, gestures, and kinetic scrolling. The Home Professional layout gives you quick and enjoyable way to check the status of the most important information.
- Launcher: The Launcher tab add a fast and convenient way to navigate through your device since it has been designed for one-handed navigation and kinetic scrolling supported. The Launcher tab consists of two pages, smart launcher and SPB Menu. The smart launcher shows the frequently used shortcuts to display and allows you to manage your favorite items. SPB Menu contains all of your device programs, settings, and tools well-organized in categories.
- Contacts: The Contacts tab helps you to manage your contacts and calls using many useful features such as call history, photo speed dial, smart contact search, Facebook integration, drag-and-drop to edit your favorite layout, kinetic scrolling, easy assigning and cropping of contact picture, set a unique ringtone for each of your favorite contacts, and more. Widget-based contacts handling allows user to allocate his favorite contacts the best way. All your favorite contacts can also be represented with a finger-friendly 3d carousel.

#### **Animated Transitions**

The animated transitions give you excellent visual cues to help you understand where you are, where you have come from, where you are going, and to keep you oriented. This feature is fully implemented in the SPB Mobile Shell tabs.

#### Kinetic Scrolling

The scrolling the lists of SPB Mobile Shell with flicking gestures feel like moving a wheel and more natural than the conventional approach of scroll bars. This feature is fully implemented in all of SPB Mobile Shell tabs and lists.

#### Widgets

Most of the program functionality is implemented by means of widgets. There are widgets for all purposes: widget-based photo contacts, Facebook, Twitter, media player, profiles, weather, world time, and wireless manager, etc.





#### **Integrated Tools**

SPB Mobile Shell comes with integrated tools such as:

Color Based Themes: SPB Mobile Shell introduces the new concept of adaptive skins. SPB Mobile Shell will
automatically change its skin when the main device color is changed. Color themes allow you to change a
color of key user interface elements (including Today) without changing the Today theme.

Wireless Manager: The Wireless Manager offers a one-tap solution to handle your device wireless

connections right from the Home Lifestyle or Launcher tab.

SPB Contacts: SPB Contacts search gives you a fast and convenient way
to find a contact. Big buttons are optimized for finger taps, but can also
be used with hardware keys. You can assign this screen to one of
Today's soft keys, so you have instant access.

 Device Lock: SPB Mobile Shell improves the usability to lock the device. Now you can lock your device using a hardware key, soft key on the Today screen or a shortcut. You can also unlock the device using only soft keys. When your device is locked the Home Screen shows you the most important information. In most cases you don't even need to unlock the device.

#### 3D Carousel

A 3d carousel with hardware accelerator support will quickly bring you to any of the most important screens. This is a live carousel which instantly shows the current state of each screen. The Gravity sensor in the 3D carousel is supported in SPB Mobile Shell 3.5 and higher.

#### 3D Email and SMS Viewer

The 3D Email and SMS viewer gives you a fast and convenient way to read your messages.







### Installation

Installation of SPB Mobile Shell is a very simple process and takes less than five minutes to complete. The following installation guide will help you.

# System Requirements

SPB Mobile Shell supports the following operating systems:

 Windows Mobile 5 Phone Edition Windows Mobile 5 Pocket PC Windows Mobile 6 Classic Windows Mobile 6 Professional Windows Mobile 6.1 Classic Windows Mobile 6.1 Professional Windows Mobile 6.5 Classic Windows Mobile 6.5 Professional



### Installing

After you have <u>downloaded</u> the SPB Mobile Shell distribution file you should install it to your device. For a successful installation you will need a Windows Phone attached to your Windows desktop PC. You will also need <u>Microsoft ActiveSync</u> software in order to install SPB Mobile Shell to your device.

When you run the software installer on your desktop PC it will ask you to accept the license agreement and will start the installation program. You will NOT be prompted for the location where you want the software to be installed. SPB Mobile Shell cannot be installed to a storage card. SPB Mobile Shell is a system service and for reliable operations it must reside in the resident storage.

Another way is to download the SPB Mobile Shell .CAB distribution file on your desktop PC then move the .CAB file to your device storage and run the file to begin the installation process.

#### Marketplace

You can install SPB Mobile Shell directly using Windows Marketplace for Windows Mobile 6.0 and above. After connecting your phone to the Internet, run Marketplace app and search for "SPB Mobile Shell".

#### Note

Microsoft ActiveSync works only with Windows XP SP2 or earlier. If you have Windows Vista, your synchronization settings will be managed through the Windows Mobile Device Center. Windows Mobile Device Center is available through the Windows Mobile Device Center page.

# Registration

You will be able to use SPB Mobile Shell until the end of the trial version period of 15 days. If you have not registered SPB Mobile Shell within this timeframe, you will need to do so to continue using it.

To obtain the serial number you need to purchase a SPB Mobile Shell software license and you will receive your serial number by e-mail.



# Uninstalling

To remove the product from your phone:

- 1. Go to Start > Settings
- 2. Open System and tap Remove Programs
- 3. Select SPB Mobile Shell from the list and tap the Remove button
- 4. Choose Yes to confirm removing



# **Getting Started**

After SPB Mobile Shell is installed on your phone it is ready to use. You can customize some settings and behavior(s). As a start, you may change the interface language. By default SPB Mobile Shell uses the language of your device. To change the language back to English (or just use another language) go to Settings > SPB Mobile Shell > System > Language.

#### **SPB Home**

SPB Home is a Today plug-in user interface that gives you up-to-date information at a glance, such as time, weather, calendar, upcoming appointments, next alarm, and shows new SMS or MMS messages, missed calls, new emails, and new voicemail. It also has a fully customizable Lifestyle layout where you can add your own favorite widgets for one-tap access.

SPB Home has two components: Professional Home (disabled by default) and Lifestyle Home. Switching between them can be done using any of the following ways:

- By flicking an upward or downward gesture.
- From the Menu button
- From the Tabs button that shows you all of SPB Mobile Shell tabs in the selected view style (carousel or tiles).

At the bottom of SPB Home, there is a toolbar that allows you to switch between SPB Mobile Shell components and access the Menu button to view the available options of the selected tab.

Tip

You can always get back to the Home screen by tapping 🎨 Menu button.

Note

To see SPB Home when your device wakes up after a long sleep, go to Settings > Today > Items, enable the Today timeout option and choose the desired timeout.







#### **Professional Home**

In SPB Mobile Shell 3.5 the Professional Home functionality is implemented by means of widgets as in Lifestyle Home. There is a wide range of widgets to choose from for all purposes. Adding of up to 5 pages to the Professional Home is also supported.

The Professional Home gives you a quick and easy way to check your device status. You can see your most important information with a quick glance, for the fastest and most direct way to use your device. For example, you can open your Inbox to read new emails with just a tap, or with a few key clicks. The Professional Home layout provides you by default with the following information:

- The weather forecast icon on the upper left for the selected city. Tap to open the weather details page where you can update forecast or access the weather options.
- In the upper middle you have three icons for email, SMS, Voice mail, and missed calls. For example, when you receive an email you will see the email icon highlighted with the number of new emails you have in your inbox. You can open your Inbox to read new emails with just a tap, or with a few key presses.
  - If you have a voicemail account on your phone, SPB Mobile Shell will automatically detect it and enable the voicemail indicator functionality. It will replace the most inactive indicator of the three indicators (Missed calls, SMS, or Email).
    - Note: The voice mail may not work due to your service provider. Some providers notify only by SMS about unread voicemails.
- With the speaker indicator on the upper right, you can adjust the
  following phone profiles on your device. Select Normal, Silent, or
  Vibrate from the profiles popup. You can also edit the normal profile. If
  you have SPB Phone Suite installed, you may use those profiles instead
  of the default ones by enabling the corresponding option in SPB Mobile
  Shell settings.
- The digital clock in the middle displays your current time and date. Tap to open the time screen for more details.
- Under the digital clock you will find the alarm notification bar when an alarm time is set and the
  corresponding option in SPB Mobile Shell settings is enabled. If you have SPB Time installed, SPB Mobile
  Shell will show the next alarm information from SPB Time instead of the system alarm clock.
- You will find the next appointment notification bars (if available) in the lower part of Professional Home.
- The calendar displays the days that correspond to the selected month and year settings. The selected date is your device's current setting. You can see a full month, three weeks, two weeks, one week or disable the calendar from the corresponding option in SPB Mobile Shell options. Tap to open the Agenda page.







3G º∭ ◀€ Œ

🥖 Start

#### Lifestyle Home

Most of the Lifestyle Home functionality is implemented by means of widgets. There are widgets for all purposes: widget-based photo contacts, media player, profiles, weather, world time, and wireless manager, etc. Make your own Home screen using those widgets and personalize your Smartphone by changing the background of the widgets screen. You can download additional free backgrounds right from your phone using the Online Catalog (Internet connection is required). There are different ways to navigate around the Lifestyle Home screen on your phone.

- The Home screen extends beyond the screen width to provide more space for adding icons, widgets, and more. Select HOME, and then slide your finger horizontally across the screen to go to the left or right side of the extended Home screen.
- Tap to view the available layout options.
- To open the available options for a widget (for example, contact or shortcut), simply tap and hold the item.
- Swipe to switch between the Lifestyle pages and slide to switch between Lifestyle and professional layouts. To swipe or slide means to quickly drag your finger vertically or horizontally across the screen.
- To drag widgets to your preferred locations, select Edit Layout then tap and hold on a widget with some pressure before you start to drag. While dragging, do not release your finger until you have reached the target position.

#### Tips

There is another easy way to get thousands of high quality backgrounds since wallpapers created for Windows desktops work very well with SPB Mobile Shell. For best results use 1280x1024 wallpapers with widescreen devices (480x800, 240x400) and 1280x800 with regular screen devices (480x640, 240x320). You can also create your own background. SPB Mobile Shell can use almost any picture as a background. To achieve best and most predictable results use the following picture sizes: Devices with wide screen (480x800, 240x400): 960x748. Devices with regular screens (480x640, 240x320): 960x588











#### Customizing Lifestyle Home Layout

You can fully customize the three pages of the Lifestyle layout in a user-friendly manner using widgets, drag-and-drop, and gestures.

- Start by adding widgets to the selected page using the Add widget button in the main menu then select the item you want to add to the Home screen. Add a clock, Twitter widget, Facebook widgets, music player, a picture frame (with slideshow support), the Google Search bar, or a calendar that shows upcoming appointments, etc...
- After adding a widget to the page, move it to the preferred location and then tap to apply the new changes. Tap and hold on a widget to view the available options.
- To remove a Home screen item, select Edit Layout option to activate Move mode then tap and hold the item on the screen you want to remove and drag the item to the remove tab. When the remove tab turns red, release it. Tap to apply the new changes.



#### Tip

You can add an Email widget for a specific Email account (e. g. Gmail) on the Lifestyle Home screen. When adding widgets choose Email and select the desired account. To enable the 3D Email viewer, tap and hold the Email widget to view the Default Action option, tap it and select Open 3D viewer.









#### Launcher Tab

The Launcher tab adds a fast and convenient way to navigate through your device. All of the pages are kinetic scrolling supported. Launcher tab have two main pages: Launcher and SPB Menu. The Launcher shows you the Pinned shortcuts, recently used programs, and finger friendly task manager. SPB Menu contains all of your device programs, settings, and tools well-organized in categories.

Use the left/right gesture to switch between Launcher main pages.

At the bottom of the Launcher pages, there is a toolbar that allows you to return to the Home tab and access the Menu button to view the available options of the selected page.

#### Tip

You can quickly access the Launcher from any application. To do that, go to Settings > SPB Mobile Shell > System and set the Override "Start" option to Yes. Now the Start menu button in the top left corner will show the Launcher instead of the standard Start menu. You can also access the standard Start menu when the Launcher page is already open.

#### Customizing the Launcher Tab

Launcher allows you to add quick shortcuts of your favorite programs and tools for one-tap access. Quick tools such as Task Manager, Wireless Manager, Adjust Backlight, Rotate Screen and Lock Device, and a few program shortcuts are added by default. They can be replaced with your preferred tools and programs.

To start customizing your favorite applications and tools, tap  $\overline{\chi}$  from the menu.

- Tap 6 to select an application to be added.
- Tap to remove an application.
- Tap when finished to apply the new changes.

#### Launcher View Modes

The Launcher page has two view modes, Simple or Advanced. Tap from the menu button to switch between the Launcher views. In both modes your favorite applications and tools will be placed at the top of the page followed by the recently used applications.

#### Customizing My Shortcuts in SPB Menu

To start customizing your favorite applications and tools shortcuts in My Shortcuts menu follow these steps:

- Open My Shortcuts folder and tap to view the available options.
- You can add a file or program to the folder using the corresponding option.
- Tap sand select an item to be removed.
- Tap when finished to apply the new changes.





Tip

To add a shortcut to a file (e. g. on a storage card) on the Launcher or Home tab, Go to SPB Menu > My Shortcuts and choose Add File from the menu. After that you can add a shortcut to the new menu item as a widget to the Home tab or as a favorite program to the launcher.

#### Contacts Tab

The Contacts tab helps you to manage your contacts and calls using many useful features such as call history, photo speed dial, smart contact search, Facebook integration, drag-and-drop to edit your favorite layout, kinetic scrolling, easy assigning and cropping of contact picture, set a unique ringtone for each of your favorite contacts, and more.

- Use the left/right gesture to switch between Contacts main pages.
- To open the available options for a contact (for example, contact or shortcut), simply tap and hold the item
- At the bottom of the Contacts pages, there is a toolbar that allows you
  to return to the Home tab and access the Menu button to view the
  available options of the selected page.

Contacts tab have three pages: Favorite Contacts, Call Log, and SPB Contacts.

#### **Favorite Contacts**

On the middle page of the Contacts tab, you can add your favorite contacts. If you make calls or send messages to certain people frequently, you can add them as favorite contacts for quicker access. Select a contact to access the contact page and make a phone call or send messages. The program allows you to get the contact's picture in several ways: choose an image file, make a photo with your built-in camera, or even select a photo from this person's Facebook profile. Crop the picture for better display.

- Tap or to add a contact to the Favorite Contacts (applies only to entries stored in Contacts on your device).
- Tap to allow editing of the added contacts. Tap a contact, when in the editing mode, to view the available options. Tap-and-hold to move a contact to other location on the page.
- Tap when finished to apply the new changes.
- All your favorite contacts can also be represented with a finger-friendly
   3D carousel. Tap to open the carousel view and set a custom ringtone or change picture of the selected contact.
- Tap to sign in your Facebook account in order to download a contact Facebook picture.
- Tap the photo, name, or number of the contact whom you want to call.
- The contact card of your selected contact is then displayed. Tap the menu button to view the available customizing options.



**Select Action** 

Open contact card

Call mobile

Send SMS

Send MMS



Note

When you add a favorite contact and there is no photo associated to that contact, the contact's first name (or last name) will be displayed.

Call Log

SPB Mobile Shell adds photos to the standard call log. This feature significantly improves the call log usability. To make a call from the call log, finger-scroll to the desired contact or phone number, tap to open the contact card.

#### SPB Contacts Search

When you start entering a phone number or contact name, SPB Contacts will automatically search and sort the contact entries that match the sequence you have entered. You can then select the desired number or contact from the filtered list to dial. To find a contact name you can enter the first letter of a contact's first name or surname. SPB Contacts will search for the letter starting from the first character of a contact name as well as from the character that appears after a space, dash, or underscore in a contact name. For example, if you tap number "5" which is associated with [j, k, l], contact names such as the following will be considered matches: Sue Jackson, Armstrong Jason, Julia, Lisa, Kim. If the matching list is long and you want to narrow down the search further,

enter another letter. Each time you tap on you will go back to the previous search screen.

Tap ito view the available options:

- You can show or hide contacts stored on your SIM card so you won't have duplicated contacts.
- You can use Filter based on contact category to organize your contacts list.

### SPB Mobile Shell Tools

The following are very useful tools that come with SPB Mobile Shell.

Task Manager: Use the task manager tool to manage your active programs list. You can activate or close any listed program. From the Menu you can close all active programs.


Wireless Manager: The wireless manager allows you to quickly turn on or off your device wireless connections such as Bluetooth, WiFi, Phone, and Flight Mode.

Theme: Tap and select a color to change the color of key user interface elements (including Today) without changing the Today theme.

Device Lock: You can lock your device using a hardware key, soft key on the Today screen or a shortcut. You also can unlock the device using only soft keys.

Phone Profiles: This tool allows you to select one of three basic phone profiles Normal, Vibrate, and Silent.







# SPB Mobile Shell Settings

SPB Mobile Shell provides a customizable user interface and behavior. You can customize such things as the Agenda View, Weather, System, Animation, Calendar Widgets, and more. To access the configuration utility, go to

SPB Menu > Settings and tap the SPB Mobile Shell options icon

# System

Customize the general system options.

- Override "Start": Enable this option to open the Launcher tab each time you tap the Start menu.
- Language: Choose SPB Mobile Shell localization. You will need to soft reset the device to apply the new changes.
- Force feedback: Enable, if you would like to receive feedback on tap and hold.
- Tap and hold support: Enable or disable the tap and hold functionality.

### Home Screen


Customize the Home screens options.

- Enabled Layouts: Select between Lifestyle and professional as your Home layout or use both.
- Page count in Professional layout: Here you can extend the Professional layout to up to 5 pages.
- Page count in Lifestyle layout: Here you can extend the Lifestyle layout to up to 5 pages.
- "Launcher" button opens: Select which one to open (Favorite or SPB Menu) when tapping the Launcher button. You can also select Remember last used option to view whatever was last used.
- "Contacts" button opens: Select which one of the contacts screen to open when tapping the Contacts button.

#### Animation

You are able to change the main tab's animation. These animated transitions give you excellent visual cue to help you understand where you are, where you have come from, where you are going, and to keep you oriented.

- Animate transitions: Enable or disable the animated transitions of SPB Mobile Shell panels.
- Tab animation on gestures: Select the desired animated transition effect that you want to apply when using gestures.





# Agenda View

Customize the Agenda display behavior.

- Show all day events: Enable to display events such as birthdays and anniversaries on the calendar.
- Show "free" appointments: Enable to display appointments with Free status on the calendar.
- Show weekends: Enable to display weekends days on the calendar.
- Weeks to show in agenda: Select how many weeks you would like to see in the Agenda view.
- Weeks to show in calendar: Select how many weeks you would like to see in the calendar view.
- Show weather: Enable to see the available weather forecast icon next to each day.

#### Weather

Select your usual temperature measurement unit and adjust the forecast update behavior.

- Update weather forecasts automatically: Select your preferred update behavior.
- Temperature scale: Select your local temperature measurement unit.
- Wind speed scale: Select your local wind speed measurement unit.
- Atmospheric pressure scale: Select your local atmospheric pressure measurement unit.

#### Note

SPB Mobile Shell doesn't provide the weather forecast. The forecast is downloaded from a third-party provider. If you have SPB Weather installed, then you can use SPB Weather forecast instead of the default one. SPB Weather allows you to change the forecast provider to get a specific location that's not included in the SPB Mobile Shell cities database.



# Backup your Settings

You can make a backed-up copy of SPB Mobile Shell settings to be restored in case of data loss. From SPB Mobile Shell options, tap the Menu button and select Backup Settings option. Fill-in the requested fields and tap Save.

# Exiting from SPB Mobile Shell

You can close SPB Mobile Shell UI and go to the Today screen at any time. To do that, open SPB Mobile Shell options > tap the Menu button and select Exit Shell. To get back to the Mobile Shell UI, tap SPB Home right softkey button in Today screen.



# **Technical Support**

This chapter contains technical support information. It includes all the information you need to assist you.

#### **About The Trial Version**

The trial version of SPB Mobile Shell includes all of the features available in the registered version. The trial version expires within 15 days after installation. You can use the trial version only to check how SPB Mobile Shell works. In order to keep using the software you need to purchase the license. There is no need to re-install the SPB Mobile Shell in order to use the full version.

To obtain the serial number you need to purchase a SPB Mobile Shell software license and you will receive your serial number by email. For more information please visit our website at: <a href="http://www.spbsoftwarehouse.com/support/general.html">http://www.spbsoftwarehouse.com/support/general.html</a>

# Before Contacting Technical Support

Please read this section before contacting Technical Support, it includes many common important issues users might face.

Refer to the Frequently Asked Questions (FAQs) in the Support section of the SPB Software website. The
FAQs may have information and helpful hints that are more current than the User Manual:
 <a href="http://spbsoftwarehouse.com/pocketpc-software/mobileshell/faq.html">http://spbsoftwarehouse.com/pocketpc-software/mobileshell/faq.html</a>

# Contacting Technical Support

Please take advantage of one of the SPB Software free technical support options:

- Choose the appropriate category for your question and submit it to our support team at: http://spbsoftwarehouse.com/pocketpc-software/mobileshell/support.html
- Ask your technical question or post feature request to forum to get quicker reply directly from the
  developer's team or user's community. Solutions to your problems are available 24 hours a day at no cost
  on the SPB Club web site. You must first register as a member before using SPB Club web support.

Please include the following information to help us isolate the problem:

- 1. The type of the device that you are using.
- 2. The software name and version number. Open SPB Mobile Shell settings and select Menu → About... to view the software name and version number (example: SPB Mobile Shell, version 3.5, Build 6389).
- 3. Any error messages that accompany the problem.
- 4. A brief description of how we can recreate the issue.